



TERMINALS




























SPECIAL NOTE: NEW Rajalah™ TERMINAL PART NUMBERS


Rajalah™ terminals and related items part numbers are now "E9-" followed by the former part number.

Example:

$$\begin{array}{ccc}
 \boxed{\begin{array}{c} W \\ P \end{array}} \text{ No.} & = & \text{E9 - CT} \\
 \text{New Number} & & \text{"E9-" Prefix Former Part Number}
 \end{array}$$

Note: Terminal part number endings of 6-32, 8-32, 10-24, and 10-32 refer to terminal thread size

 ☑ No. E9-CT	 ☑ No. E9-SS	 ☑ No. E9-R-2	 ☑ No. E9-SF	 ☑ No. E9-TT
 ☑ No. E9-CT-TS 8-32 E9-CT-TS 10-32	 ☑ No. E9-SS-TS 10-32	 ☑ No. E9-SR	 ☑ No. E9-HS 6-32 E9-HS 10-32	 ☑ No. E9-CT-BS 6-32 E9-CT-BS 8-32 E9-CT-BS 10-32
 ☑ No. E9-SS-BS 6-32 E9-SS-BS 8-32 E9-SS-BS 10-32	 ☑ No. E9-HT 6-32 E9-HT 8-32 E9-HT 10-32	 ☑ No. E9-SX-1 6-32 E9-SX-1 10-32	 ☑ No. E9-CT-SS	 ☑ No. E9-ACT
 ☑ No. E9-ASS	 ☑ No. E9-CHT	 ☑ No. E9-BS 6-32 E9-BS 8-32 E9-BS 10-24 E9-BS 10-32	 ☑ No. E9-458-9 10-32	 ☑ No. E9-RAC
 ☑ No. E9-RASS	 ☑ No. E9-EBS 6-32 E9-EBS 10-32	 ☑ No. E9-457-6 6-32	 ☑ No. E9-SS-SOS	 ☑ No. E9-R-SOS

Please order by  No.

rev. 5-1-07

E30